31/08/2001

ENGINE OIL PUMP CHAIN BELT SUCTION





M2220850

- TURBO DIESEL DK5ATE

1	1001 85	01	ENGINE OIL PUMP
4	1133 13	01	DISCHARG TON DIAM 16X25
5	1157 11	01	PISTON SPRING 6 BARS
6	1157 19	01	GUIDE PIN DIAM 7 LONG 40
8	1033 12	01	OIL PUMP CHAIN
70	6925 A9	03	SCREW WITH BASE 6X100-60
71	6920 37	03	SCREW RLX 6X100-45
72	6913 J1	02	SCREW DIAM 6X100-20
73	6968 97	01	PIN 8,5X12
74	6925 69	01	SCREW WITH BASE DIAM 6X100-30

31/03/2001

ENGINE OIL PUMP CHAIN BELT SUCTION





M2220700

- DIESEL XUD11A OR TURBO DIESEL XUD11ATE OR TURBO DIESEL XUD11BTE

1		1001 66	01	**ENGINE OIL PUMP**
2		1018 49	01	**OIL SUCTION** TO O 06778
3		1033 06	01	**OIL PUMP CHAIN**
4		1133 13	01	**DISCHARG PISTON** DIAM 16X25
5		1157 11	01	**PISTON SPRING** 6 BARS
6		1157 19	01	**GUIDE PIN** DIAM 7 LONG 40
7		1047 18	01	**PANEL**
8	*1011 14*		01	*SCREW DIAM 7X100-75*
	RP	1011 05	01	*ON CONDITION TO PUT UP THE WASCHER*
	+	6962 28	01	
30	*0163 21*		01	*CASING PLUG 16X150-12*
	RP	0163 93	01	
31		6921 32	01	**CAPSCREW** DIAM 7X100-65
32		6917 92	02	DIAM 6X100-20
33		6922 60	03	**SELF-TAP SCREWS** DIAM 6X100-45
34		6921 53	01	**CAPSCREW** DIAM 6X100-35
35		6962 04	01	**FLEXIBLE WASHER** 6X12.2-0.5
36		79 03 058 019	03	**SPRING WASHER** 8X16-1.4
37		6962 12	03	**FLEXIBLE WASHER** 7X13.7-0.8

31/08/2001

ENGINE OIL PUMP CHAIN BELT SUCTION





[03/97] M2220300

M2220300

- INJECTION ES9J4

1	*1001 88* **RP 1001 A3**		01 01	*ENGINE OIL PUMP*
				SCREW
2	**1011 15**		11	DIAM 6X100-28
3	**1011 16**		03	DIAM 6X100-60
70	**6968 82**		02	**CENTRING PIN** DIAM 6X12

31/08/2001

ENGINE OIL PUM.P CHAIN BELT SUCTION





[1058] M2220200

M2220200

- INJECTION ZPJ OR INJECTION ZPJ4

1	1001 27	01	**ENGINE OIL PUMP**
2	1023 11	01	**PUMP CONTR PINN**
3	1028 12	01	**OIL PUMP CHAIN**
4	1034 07	01	**INT PINION** 7 DTS
5	1157 15	01	**PISTON SPRING**
6	1158 06	01	**SPRING RETAINER**
70	6915 26	01	**SELF-TAP SCREWS** DIAM 7X100-25
71	6968 04	01	**PIN** 4X45
73	6947 77	01	**PLAIN WASHER** DIAM 6X12-1,2
74	6915 84	01	**CAPSCREW** DIAM 6X100-12

31/08/2001

ENGINE OIL PUMP CHAIN BELT SUCTION



- INJECTION XU10J4R

1		1001 77	01	**ENGINE OIL PUMP**
2		1018 43	01	**OIL SUCTION**
3		1011 11	01	**PUMP FIX SCREW** DIAM 7X100-70
4		1012 07	01	**OIL PUMP SPACER** EP 1,1
5		1133 13	01	**DISCHARG PISTON** DIAM 16X25
6		1157 11	01	**PISTON SPRING** 6 BARS
7		1033 10	01	**OIL PUMP CHAIN** 52 LINKS
				PANEL
8		1047 08	01	
9		1047 11	01	-WITHOUT AIR CONDITIONING GEARBOX BE3 TO O 07083 OR BVM ME OR BVA
		1047 10	01	- AIR CONDITIONING OR GEARBOX BE3, WITHOUT AIR CONDITIONING FROM O 07084 TO O 07972 OR GEARBOX BE3R, WITHOUT AIR CONDITIONING FROM O 07973
10		1011 12	01	**SELF-TAP SCREWS** DIAM 7X100-85
11	*1011 14*		01	*SCREW DIAM 7X100-75*
	RP	1011 05	01	*PROVIDED THAT DELETE THE WASHER*
	+	6962 28	01	
12		1157 19	01	**GUIDE PIN** DIAM 7 LONG 40
13		0163 78	02	**PLUG** 16X150
				SELF-TAP SCREWS
[illegible]		6922 80	06	DIAM 6X100-25
[illegible]		6922 54	02	DIAM 6X100-20
72		6952 28	01	**FLEXIBLE WASHER** 8X15-0,5

M2220150

31/08/2001

ENGINE OIL PUMP CHAIN BELT SUCTION



07/1999 M12220100

M2220100

- TURBO INJECTION XU10J2TE

1		1001 66	01	**ENGINE OIL PUMP**
2		0163 73	02	**PLUG** 16X150
3		1133 13	01	**DISCHARG PISTON** DIAM 16X25
4		1157 11	01	**PISTON SPRING** 6 BARS
				OIL PUMP CHAIN
5		1033 06	01	TO O 08133
		1033 09	01	FROM O 08134
				PANEL
6		1047 12	01	-WITHOUT AIR CONDITIONING
		1047 13	01	-AIR CONDITIONING
7		1047 08	01	
8	*1011 14*		01	*SCREW DIAM 7X100-75*
	RP	1011 05	01	*PROVIDED THAT DELETE THE WASHER*
	+	6962 28	01	
9		1011 11	01	**PUMP TX SCREW** DIAM 7X100-70
10		1011 12	01	**SELF-TAP SCREWS** DIAM 7X100-85
11		1157 19	01	**GUIDE PIN** DIAM 7 LONG 40
				OIL PUMP SPACER
12		1012 07	01	EP 1,1 TO O 08133
		1012 08	01	EP 0,7 FROM O 08134
				SELF-TAP SCREWS
70		6922 54	04	DIAM 6X100-20
71		6923 53	04	DIAM 6X100-40
72		6962 28	01	**FLEXIBLE WASHER** 8X15-0,5

31/08/2001

ENGINE OIL PUMP CHAIN BELT SUCTION





M2220010

INJECTION XU10J2

1		1001 80	01	**ENGINE OIL PUMP**
2		0163 78	02	**PLUG** 16X150
3		1133 13	01	**DISCHARG PISTON** DIAM 16X25
4		1157 11	01	**PISTON SPRING** 6 BARS
5		1157 19	01	**GUIDE PIN** DIAM 7 LONG 40
6		1012 07	01	**OIL PUMP SPACER** EP 1,1
7		1033 10	01	**OIL PUMP CHAIN** 52 LINKS
8		1011 11	01	**PUMP FIX SCREW** DIAM 7X100-70
9		1011 12	01	**SELF-TAP SCREWS** DIAM 7X100-85
10	*1011 11*		01	*SCREW DIAM 7X100-75*
		OR 1011 05	*C1*	*PRVIDED THAT DELETE THE WASHER*
		+ 4962 28	*01*	
30		6962 28	01	**FLEXIBLE WASHER** 8X15-0,5
31		6922 80	06	**SELF-TAP SCREWS** DIAM 6X100-25